



DARK ENERGY
SURVEY

DECam CCD Quantum Efficiency Measurements

Vic Scarpine
Fermilab



CCD Quantum Efficiency

DARK ENERGY
SURVEY

DES science requirements place a requirement on the acceptable QE especially in the NIR.

- Absolute QE [g r i z] > [60% 75% 70% 65%]
- Requirement to measure absolute QE for each device

Absolute QE = #e- / #photons

$$QE(\lambda) = (N_{ADU}(\lambda) / G) * (h * c) / (K * P(\lambda) * t * \lambda)$$

Sensitive to G (gain) and K (light ratio at CCD to sphere)


Relative QE removes G and K but gives QE spectrum shape

$$QE(\lambda) / QE(\lambda_0) = N(\lambda) / N(\lambda_0) * (P(\lambda_0) * \lambda_0) / (P(\lambda) * \lambda)$$



Measurement Setup

DARK ENERGY
SURVEY



Calibrated photodiode-to-dewar light ratio determined by using calibrated photodiode at CCD location.

$$P(\text{CCD}) = K * P(\text{sphere})$$

CCD illumination biggest concern:

- Use 2 sphere setup to minimize non-uniform lighting
- Most devices measured with filter wheel at 400, 480, 600, 700, 800 and 1000 nm
 - Use monochromator on a few devices
- Use collimating baffle to get good flat field (~3%) and minimize stray light




Absolute QE Measurement

DARK ENERGY
SURVEY

Absolute QE for single device for right and left channels


- Comparison to different device measured at LBNL
- *Reduced blue response may be to back surface issue*
- Biggest uncertainty in gain ($\sim 3\%$) and incident light levels ($\sim 10\%$)





Relative QE for Two Devices

DARK ENERGY
SURVEY



Relative QE
(normalized to 800 nm) for two DECam
CCS from
engineering runs Lot
1A (red) and lot 1B
(black)


- *Difference in blue may be due to variation in CCD back surface*

Shows QE device-to-device variation < 5% (except in blue)



QE versus Temperature

DARK ENERGY
SURVEY



Relative change in QE
versus temperature

- ~ 5% QE changes at 1000 nm for a temperature change of 10 degrees

***Implies we need
temperature stability
of 1 degree K at each
CCD to meet spec
across all
wavelengths***