

Adam Sypniewski David Gerdes

University of Michigan

#### Objectives

- Measure misalignment effects
  - Measure relative displacement of prime focus with respect to the primary mirror
- Correct misalignment
  - Feed back displacement data to hexapod
- Better data!


#### **BCAMs**

- Brandeis CCD Angle Monitors
- 2 red diode lasers, 1 CCD
- Field of view: angular cone 30mrad x 40mrad
- Relative accuracy: 5µrad

At 10m, this corresponds to:


Field of view: 30 cm x 40 cm

Relative accuracy: 50µm



## Mounting the BCAMs


- Kinematic mount
- Two angular degrees of freedom





## Mounting the BCAMs

- BCAM #1: Outside of prime focus cage
- BCAM #2: Outside wall of primary mirror cell



# Mounting the BCAMs

BCAM #1


BCAM #2






## Hardware/Software Control

- LWDAQ driver acts as a "hub" for BCAMs
- LWDAQ can be accessed over internet



#### LWDAQ Installation


Located in Cassegrain cage



# **Preliminary Results**

#### X-Positions (mm)

#### Y-Positions (mm)



Accuracy: ~5μm

Readout rate: 2 Hz

Note: tracking at 20°S

#### Conclusions & Future Work

- Misalignment/hysteresis effects clearly present
- BCAMs seem to be an excellent method for measuring these effects

- Better mounting points needed
- Integration into new TCS
- Hexapod feedback is feasible